



SEC-CAMIP30  
SEC-CAMIP40  
SEC-CAMIP40EC



MANUAL (p. 2)  
IP Cam System User's Manual

Manual IPCAM V4.0.3 EN


# Contents

1	IPCAM system .....	3
1.1	How to install .....	3
1.2	How to Add a device into IP Cam System.....	5
1.3	Video via Internet.....	6
1.4	How to use IP Cam System.....	8
2	Search Tool .....	17
2.1	How to use Search Tool.....	17
2.2	Connect IP Cam and computer .....	19
3	IP Cam Mobile.....	21
3.1	Video monitoring on iPhone .....	21

# 1. IPCAM system

## 1.1 How to install

Insert the software CD in your CD-R device, start the installation. Choose Shelexec.exe to start installing the software or check the disc contents and click the startup.html file to open the start up page. The following starting screen appears.




Click "install software".




1.1.1 Click **Next** to start the installation.



1.1.2 Click **Next**.




1.1.3 Click **Install**.



1.1.4 Click **Finish** to complete IP Cam System installation.

Check the Finished box if you wish to run **User's Manual** automatically.

**Note: Adobe Reader is needed**



Run DB Upgrade Tool to check if your application is ready for an upgrade. Click Upgrade if it prompts **Incompatible database version** as figure. Then close DB Upgrade Tool and restart IP Cam System.




**Tips:**

Start Menu → All Programs → IP Cam System → DBUpgrade Tool



## 1.2 How to Add a device into IP Cam System

1. Select an empty channel
2. Click  **Add a device**
3. Press **Search** or type in ID and Password of your device  
(Note: **Search** function can be used under local network only)
4. Press **Save**
5. Click **Start all cameras** in IP Cam setting




### Notice:

1. Device can be searched automatically. Please check the Home plug LED signal if no device found (only SEC-CAMIP40, SEC-CAMIP40EC)
2. If the device is automatically searched, the User ID and User Password fields must be set before saving. And, the specified ID & Password will update the original ID & Password.

### 1.3 Video via Internet

1. Select an empty channel
2. Select  **Add one device**
3. Type in your **Device ID / Password** (Printed on the product body)  
Type in your **User ID / Password** (Set up by user, can be edited, please refer to Search Tool )
4. Press **Save**
5. Click **Start all cameras** in IPCam setting




**Notice:**


Make sure the camera is connected to the internet if failed to load video.

If the problem still can't be solved, follow the steps below and provide the information to your supplier.


1. Right click mouse on the display channel
2. Select TST
3. Provide the information to your supplier



## 1.4 How to use IP Cam System



### A. IP Cam Setting



#### Edit Device Setting

Edit device Basic Info / Alarm Setting / Schedule recording



#### Add one device

Add a new device on display channel.



#### Delete selected device

Delete the selected device from display channel.



#### Start all cameras

Start all connection with camera device.



#### Stop all cameras

Stop all connection with camera device.




#### Edit Device Setting

Edit device Basic Info / Alarm Setting / Schedule recording

## Basic Info


- **Device ID**  
Each individual ID shown on back of IP Cam
- **Device Password**  
Each individual password shown on back of IP Cam
- **Channel Name**  
Edit camera name.
- **User ID / User Password**  
Each user's personal ID and password



## Alarm Setting:

After selecting Enable Alarm, click **Motion detection setting** to adjust the sensitivity and Email setting.

- **Enable Alarm**  
Set to **Full time alerted** or **Schedule alert**
- **Motion detection**  
Click **Setting** to adjust motion detection sensitivity



Week	Start	End	Trigger method	Alert method

- **Alarm Methods**  
Alarm sound/Snap shot/Recording/Send Email
- **Email setting**  
Refer to your outlook account information of SMTP/Account/Password.

### Note:


Email alert can work properly only when Internet is connected.

➤ **Schedule Alert**

-  Add one duration
-  Edit selected duration
-  Delete selected duration


Select **Add one duration** to schedule alarm

Set days and time or full time alarming



The icons below shows the status on this device

-  Alarm has been enabled
-  Alarm detected on channel
-  Schedule recording



## Schedule Recording:


### > Select enable schedule recording

-  Add one duration
-  Edit selected duration
-  Delete selected duration




Select **Add one duration** to schedule recording

Set days and time or full time recording



## B. Display Setting

- a. 4 Channel
- b. 6 Channel
- c. 9 Channel
- d. 16 Channel




### Full Screen Mode:

Double left click mouse of selected channel to switch to full screen mode, double left click again to switch back.

## C. Main function

- a. Search Tool
- b. History
- c. System Setting
- d. About IP Cam System







## Search Tool

Use to set up IP Cam (Local network only)




## System Setting

- **Reconnect IP Cam**  
Auto reconnects IP Cam when disconnected.
- **Alarm Setting**  
**Sound effects file**  
Select your preferable sound when alarming.
- **Snap shot and video recording path**  
Setup save folder for the recorded files and snapshots.
- **Overwrite video**  
Set up the occupy disk space.
- **Set up the system start status**  
video stretch/status bar/confirm when system close
- **Stretch Video**



- a. Normal Mode
- b. Stretch video
- c. Right click mouse on selected image

- **Status Bar**



1. When new version is available, this field will show it. Click to enter download page.
2. This field shows the link mode of specified video channel. It is a texture description of the icon on the up-right corner of video display:

[LAN Mode] Your PC and IPCam are on local area network. (icon )

[P2P Mode] Images directly come from IPCam on Internet. (icon )

[Relay Mode] Images go through relay server. Slow frame rate. (icon )

3. This field shows PC's IP.
4. This field shows the date and time when IPCam executed.

➤ **Confirm when system close**




 **History of video/ snapshot**




**Playback video**

1. Select device
2. Choose history data
3. Playback back




## History of snapshot




### About IP Cam System

Version of your IP Cam System and User's Manual.



## D. Display Channels



- a Relay Mode
- b Video source via local network
- c Video source via Internet
- d Frames per second
- e Video recording
- f Snapshot manually

## Shortcut function

Right click on the display channel




- **Disconnect**  
Disconnect the device.
- **Stretch video**  
Stretch video display.
- **Edit device**  
Edit device Basic Info/Alarm Setting and Schedule recording.
- **Delete this device**  
Delete the selected device.

- **Snapshot**  
Take picture of the selected device.
- **Manual recording**  
Start recording instantly.

## E. Device Control

- **Selected device**  
Shows the IP address/ Device ID of the selected camera
- **Pan/Tilt Control**  
For control the camera angle. (For selected model only)
- **Video adjust**  
Adjust light condition/resolution/video quality.  
Light condition: Indoor/Outdoor/Night vision  
Resolution: 640\*480/320\*240/160\*120  
Video quality: From highest to lowest



## 2 Search Tool

### 2.1 How to use Search Tool




Click **IP CAM Setup**

Search Tool helps setting up your IP cam directly.

**Note:**

This software can be operated under the local network only

- A Device List
- B Basic Settings
- C Authentication of Device



#### A. Device List

No.	DeviceID	DevicePassword	IP	MAC	P2P Server	FirmVer
3	AAAL01057	11888643	192.168.2.23	00:60:6E:51:74:C2	www.p2pipcam.com	
4	AAJ0045	58156807	192.168.2.29	00:60:6E:51:45:B4	www.p2pipcam.com	
5	AAJ00458	86356283	192.168.2.26	00:60:6E:51:44:8C	www.p2pipcam.com	

1. Search for cameras under local network
2. Info of camera found

**Note:**

In this preview window, all the changes are directly saved to your device.

- **Brightness**  
Select brightness by clicking on **Low**, **Standard**, or **High**.
- **Quality**  
+: for clear picture and bigger file size  
-: for less picture quality and smaller file size
- **Environment**  
Please select the **Indoor**, **Outdoor** or **Night** mode, depending on the environment condition.
- **Position**  
Normal / Flip / Mirror



## B. Basic Settings




- **Environment**  
Night / Indoor / Outdoor
- **Frequency**  
50 Hz or 60Hz based on your AC power's frequency.
 

USA and countries in South America	60Hz
Taiwan	60Hz
Japan	50Hz / 60Hz both
Most of countries in European / Middle East / Africa	50Hz

## C. Authentication

Set up your personal account and password. Once been set, It can only be changed or deleted under local network




### Notice:

User Authority is for the security use, we strongly suggest you to set up your own ID and password once you begin to use the product.


## 2.2 Connect IP Cam and computer

Use Search Tool to start the connection



1. Please click **search**, then select an **IP cam** on the list.

Set IP address for PC and Camera





2. Make sure the IPs of LAN and IPCAM are the same, except the last block



## Changing IP Address in Windows

Click **Start** button → Right click **My Network Places** icon → click **Properties** → Right click **Local Area Connection** icon → Click **Properties** → click **Internet Protocol [TCP/IP]** icon → click **Properties**



### 3. IP Cam Mobile, see also starting screen

Please download the dedicated video monitoring software for Apple OS4 and Android operation system. For further detail please visit web page as below:

<http://www.p2picam.com/3g>

All other Smart Phones users please use web browser to visit Allmycloud server as below:

<http://www.allmycloud.com>

Please refer to the example for iPhone as below and refer to the user's manual of your phone for more operation details.

- **Video monitoring on iPhone**

To use the App Store, iPhone must be connected to the Internet.

P2P IPCam Lite is free; you can download it without charge.

Once you download it, it's immediately installed on your iPhone. Then follow the steps below:

