

## Öffnen des Gerätes *How to open your Device*

Die meisten Gehäuse sind geclippt und können einfach aufgehebelt werden. Achten Sie darauf, dass die Clips nicht beschädigt werden.

### **Achtung:**

- **Beim Öffnen des Gehäuse erlischt die Garantie**
- **Für Schäden am Gerät kann keine Haftung übernommen werden.**

*Most of the housings are clipped and can be opened easily. Take care that the clips will not be damaged during the opening process.*

### **Attention:**


- ***the claim for replacement expires when you open the housing***
- ***For damages we assume no liability***

Beginnen Sie damit, Ihr Gerät mit dem Rücken auf eine weiche Arbeitsunterlage zu legen.

Benutzen Sie nun das Öffnungswerk-zeug, beginnen Sie es am oberen Teil des Gehäuses einzustecken und das Gehäuse leicht aufzuhebeln.

Hebeln Sie mit dem zweiten Öffnungswerk-zeug nach und nach die Seite auf.

Wenn eine Seite komplett geöffnet ist, können Sie den Gehäusedeckel lösen.



*Begin by laying your Device on it's back on a soft work surface.*

*Usind the opening tools, begin to pry open the case, starting with the top corner of the Device.*

*With the opening tool wedged inside the case, carefully work your way up to the top of the housing, unclipping the case clips as you go.*

*With one side of the case fully unclipped, you can now flip the main section on the Device face down. Be careful, not to damage the housing.*